DSM™ / IN-CAB QUICK REFERENCE

# JBT Tempest II Joystick Trainer

## JOYSTICK FACE / SWITCH POSITIONS

### 01 Fluid selector
Up / D: Type I deice
Center / O: Off
Down / A: Type IV anti-ice

### 02 Flow selector
Up: High flow, Type I or Type IV
Down: Low flow, Type I only

### 03 High-flow spray fan
Hold up: Narrow the fan
Hold down: Widen the fan
Release to stop adjusting




ACTUAL JOYSTICK FACE

### 04 Air cannon
Up: Cannon on
Down: Cannon off
Hold trigger for air output

### 05 Fluid enable
Up: Enable fluid output
Down: Disable fluid output
Air cannon can still run

### 06 Air / fluid mode
Up: Fluid over air
Center: Air only
Down: Fluid injection

## GRIP MOVEMENT AND TRIGGER

### Tilt / aim the nozzle
Push away to aim down. Pull toward you to aim up. Tilt left or right to aim. Tilt diagonally to combine directions.

### Twist / rotate the bucket
Twist the grip left or right to rotate the bucket in that direction. You can twist while tilting the grip.

### Back trigger / control output
Squeeze and hold for the selected air or fluid output. Release to stop.

**Review draft: Confirm this guide against your truck and station procedures before placing it in a cab.**

Ask your station trainer to verify the air/fluid selector behavior with the air cannon off.